

Индикаторы давления

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: yzi@nt-rt.ru || сайт: <https://yildiz.nt-rt.ru/>

Order No	Manometer Scale	Max Pressure	Flow Diameter	Connection Size
51315	0-315 bar	0-230 bar	Ø 63	G 1/4"
51016	0-16 bar	0-10 bar		

Order No	Manometer Scale	Max Pressure	Flow Diameter	Connection Size
51140	0-40 bar	0-25 bar	Ø 63	G 1/4"
51102	0-2,5 bar	0-1,5 bar		

Order No	Manometer Scale	Max Pressure	Flow Diameter	Connection Size
53315	0-315 bar	0-230 bar	Ø 63	G 1/4"
53006	0-6 bar	0-4 bar		

ARGON-CO₂ MANOMETER

Order No	Manometer Scale	Max Pressure	Flow Diameter	Connection Size
59315	0-315 bar	0-230 bar	Ø 63	G 1/4"
59032	32 l/dk.	0-21 l/dk.		

Order No	Manometer Scale	Max Pressure	Flow Diameter	Connection Size
51202	0-2,5 bar	0-1,5 bar	Ø 63	G 1/4"

TEST FLOWMETER

Order No	Description
FM25	Test Flowmeter Argon - CO ₂



51315



51016



51140



51102



53315



53006



Order No	Manometer Scale	Max Pressure	Flow Diameter	Connection Size
59012-50	0-12 l/dk.	0-12 l/dk.	Ø 50	G 1/8"
51140-50	0-40 bar	0-25 bar		
51315-50	0-315 bar	0-230 bar		
51102-50	0-2,5 bar	0-1,5 bar		
51006-50	0-6 bar	0-4 bar		



51102-50



51140-50



59012-50



51315-50

Argon & CO2 Flowmeter Tube Set 30l/min 50168-30

Flowmeter Tube Set Argon-CO2 30 l/min



Acetylene Pressure Gauges (Manometers) 0-40 Bar 51140-20

Connection :G 1/4"
Outer Diameter :Ø 63
Using Pressure :0-20 bar
Manometer Pressure :0-40 bar



Pressure Gauges (Manometers) 0-200 Bar 51200

Connection :G 1/4"
Outer Diameter :Ø 63
Using Pressure :0-100 bar
Manometer Pressure :0-200 bar



Pressure Gauge (Manometer) 0-100 Bar 52100

Connection :G 1/4"
Outer Diameter :Ø 63
Using Pressure :0-50 bar
Manometer Pressure :0-100 bar



Pressure Gauge (Manometer) 0-200 Bar 52200

Connection :G 1/4"
Outer Diameter :Ø 63
Using Pressure :0-150 bar
Manometer Pressure :0-200 bar



Pressure Gauge (Manometer) 0-6 Bar 54006

Manometer Pressure :0-6 bar
Pressure Used :0-4 bar
Outer Diameter :Ø 63
Connection :G 1/4"



Pressure Gauge (Manometer) 0-2.5 Bar 54202



Pressure Gauge (Manometer) 0-315 Bar 54315

Connection :G 1/4"
Outer Diameter :Ø 63
Using Pressure :0-230 bar
Manometer Pressure :0-315 bar



Argon & CO2 Outlet Pressure Gauges 0-12 l/min 59012-50

Connection Size :G 1/8"
Outlet Diameter :50 mm
Using Pressure :0-3,5 bar
Manometer Pressure :0-6 bar



Argon & CO2 Outlet Manometer 0-32 Bar

Connection Neck :R 1/4"
Outer Pressure :63 mm
Using Pressure - Argon :0-22.5 l/dak
Using Pressure - CO2 :0-21 l/dak
Manometer Pressure :0-32 l/dak



Argon & CO2 Outlet Manometer 0-32 Bar

Connection Neck :R 1/4"
Outer Pressure :63 mm
Using Pressure - Argon :0-22.5 l/dak
Using Pressure - CO2 :0-21 l/dak
Manometer Pressure :0-32 l/dak



По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: yzi@nt-rt.ru || сайт: <https://yildiz.nt-rt.ru/>